

-PREP STEPS-



Overlay on Ceramic Tile



Ceramic Tile has a tremendous surface tension that contributes to it being such a difficult-to-stick surface.

Our prep steps are as follows...

- 1) Clean well with Denatured Alcohol**
- 2) Apply Adesivo to entire surface to create a “tooth”
Allow to dry a minimum of two hours**
- 3) Trowel on skim coat of Serico to create smooth surface
(could take more than one coat)**
- 4) Allow to sit at least Overnight for full cure**
- 5) Sand Serico lightly, clean**
- 6) Overlay project**
- 7) Allow to sit overnight to dry**
- 8) Next day-sand rough areas with 220 grit on a palm sander**
- 9) Clean with water only, hydrate and stain**
- 10) Allow stain to sit for 3 hours**
- 11) Clean residue and apply Hardener *if non-food surface***
- 12) Wax with Brown Gravy Wax**
- 13) If food is to be prepared or handled on surface, or a
HIGH_Gloss sheen is preferred, skip
Hardener and wax---instead apply Solvent Topcoat**