

Overlay on Ceramic Tile

Ceramic Tile has a tremendous surface tension that contributes to it being such a difficult-to-stick surface

Our prep steps are as follows...

Etch entire surface to create a "tooth"

Clean well with Denatured Alcohol

Trowel on skim coat of Serico to create smooth surface
could take more than one coat

Allow to sit at least Overnight for full cure

Sand Serico lightly, clean & prime with Bonding Primer

While Bonding Primer is damp, Overlay project

Allow to sit overnight to dry

Next day-sand rough areas with 220 grit on a palm sander

Clean with water, hydrate and stain

Allow stain to sit for 3 hours

Clean residue and apply Hardener if non-food surface

Wax with Brown Gravy Wax

If food is to be prepared or handled on surface,

skip Hardener and wax-instead apply Countertopcoat.