

Overlay on Existing Concrete

Dry Concrete has a difficult time accepting more concrete

Our prep steps are as follows...

Clean all loose materials off floor

Degrease any oil spots with oven cleaner or a poultice

A good poultice is Kitty litter and acetone under a vapor barrier like a tupperware bowl taped to the floor

Allow to sit overnight

Mop with soap and water

Allow to dry completely

Prime generously with Bonding Primer

While Bonding Primer is damp, Overlay project

Allow to sit overnight to dry

Next day-sand rough areas with 220 grit on a palm sander

Clean with water, hydrate and stain

Allow stain to sit for 3 hours

Clean residue and apply Hardener

3 coats with at least 30 minutes between

Buff in Brown Gravy Wax

Buff to a sheen approx 10 min later