

Overlay on Formica or Corian

Formica is a very common, very difficult to adhere surface

However, there are primers out there designed to adhere to Formica without wasting time trying to sand the surface. When using a product like "Serico", surface can be leveled at same time to eliminate drip edges and seams.

Our prep steps are as follows...

Clean with Denatured Alcohol

Tape any seams with fiberglass tape and bed layer of Serico

Trowel on skim coat of Serico over everything

Allow to sit Overnight for full cure

Sand Serico lightly, clean & prime with Bonding Primer

While Bonding Primer is damp, Overlay Counter

Allow to sit overnight

Next day-sand rough areas with 220 grit on a palm sander

Clean with water, hydrate and stain

Allow stain to sit for 3 hours

Clean residue and apply Hardener if non-food surface

Wax with Brown Gravy Wax

If food is to be prepared or handled on surface,

skip Hardener and wax-instead apply Countertopcoat.