

-PREP STEPS-



Overlay on Sheetrock or Plaster



The key here (*as in all Overlay Applications*) is to get the surface ready to the point that it would accept latex paint first.

Our prep steps are as follows...

- 1) Clean all dust from surface**
- 2) Prime surface with a good PVA primer or
Painter-specified paint primer**
- 3) Allow to dry completely**
- 4) Overlay project**
- 5) Allow to sit overnight to dry**
- 6) Next day-sand rough areas with 220 grit on a palm sander**
- 7) Clean with water, hydrate and stain**
- 8) Allow stain to sit for 3 hours**
- 9) Clean residue and apply Hardener
3 coats with at least 30 minutes between**
- 10) Buff in Brown Gravy Wax
Buff to a sheen approx 10 min later OR**
- 11) If High-Gloss is desired, skip Liquid Hardener and Wax---
instead, roll-on Solvent Topcoat in two coats 2 hours apart.**