

# Overlay on Wood Floor

Wood creates issues with grain raise, flexion and tannin bleed

Our prep steps are as follows...

Glue and Screw "HardiBacker" or

"HardiPanel" to wood subfloor

Use Galvanized screws-Cover them with Serico

Tape all seams with fiberglass tape and Serico

Trowel on skim coat of Serico all over to create

smooth surface-could take more than one coat

Allow to sit at least Overnight for full cure

Sand Serico lightly, clean & prime with Bonding Primer

While Bonding Primer is damp, Overlay project

Allow to sit overnight to dry

Next day-sand rough areas with 220 grit on a palm sander

Clean with water, hydrate and stain

Allow stain to sit for 3 hours

Clean residue and apply Hardener

3 coats with at least 30 minutes between

Buff in Brown Gravy Wax

Buff to a sheen approx 10 min later